

9.3 Replaceable Spare Parts List

When ordering spare parts, be sure to include the analyzer serial and model numbers.

Description	P/N
Cable – Display to Main Board	13230920
Cable – Sensor to Main Board	13231590
Connector - (10 pin)	50980743
Connector - (4 pin)	50980755
Display assembly with PCB	15330110
Electrolyte	DF-EO5
Electrolyte for Model 310-H0050 only	DF-EO6
Feet - Rubber	83950001
Filter Element - Coarse	64005011
Filter Element - Fine	64005012
Flow Meter	11220841
Flow Meter w/Valve	11220842
Fuse 24 VDC Operation - 1A	45002421
Fuse 100-240 VAC Operation - 2.5A	45002521
Handle Assembly	65000000
Manual	99000029
PCB – Main Interface	10429210
PCB - CPU	10429200
Power Cord	59017300
Power Supply (100-240VAC)	47500024
Pump – 24 VDC	63000310
Sensor	Call Delta F
Sensor Cap - Black	15015240
Sensor Cap - Green	17323100

Table 14: Replaceable Spare Parts