

9.3 Replaceable Spare Parts List

When ordering spare parts, be sure to include the analyzer serial and model numbers.

Description	P/N
Connector – (10 pin)	50980743
Connector – (4 pin)	50980755
Display assembly with PCB	15330110
Filter Element – Coarse	64005011
Filter Element – Fine	64005012
Flow Meter	11220841
Flow Meter w/Valve	11220842
Fuse 1A 24V Operation	45002421
Fuse 2.5A 100-240VAC Operation	45002521
Manual - Instruction	99000039
Pump – 24 VDC	63000310
Sensor	Call Delta F

Table 11: Replaceable Spare Parts